

LASER PRODUCTS APRIL, 2011



DOCTOR BLADE

hp 3906(ax), 4092

hp 435, 436, 285, 278

hp 2612, 5949, 7553, 505

hp 7115, 2613, 2624

hp 4096, 4127, 8061, 4191

hp 2610

hp 6511, 7551, 255

hp 1338, 1339, 5942, 5945

hp 4129

hp 7516

hp 540-543, 530-533

hp 364

hp 9720-9723

hp 9730-9733

hp 6000-6003

hp 7560-7563, 6470-6473, 7581-7583

hp 5950-5953

ML1210, Xerox Phaser 3110, 3210, Lexmark E210

ML1710, SCX4200, 4216, SF560, Xerox Phaser 3115, 3120, 3121, 3130, Xerox WC 3119

ML2250, Xerox Phaser 3150, Xerox WC PE120

ML2550

ML6060, Xerox Docuprint P1210

ML3050, Xerox Phaser 3428

ML1610, 1640, 2010, 2240, Xerox WC PE220

TN2025, Xerox Docuprint 203/204

Xerox Docuprint 240/340



LASER PRODUCTS APRIL, 2011



WIPER BLADE

hp 3906(ax), 4092, 7115, 2613, 2624, 5949, 7553

hp 2612

hp 4096, 2610, 6511, 9700-9703, 3960-3963, 7551, 255, 4191

hp 4127, 364, 8061

hp 4129, 7516, 4182, 8543

hp 9720-9723

hp 9730-9733

hp 6000-6003

hp 7560-7563, 6470-6473, 7581-7583

hp 5950-5953

hp 1338, 1339, 5942, 5945

ML1210, Xerox Phaser 3110, 3210, Lexmark E210

ML1710, SCX4200, 4216, SF560, Xerox Phaser 3115, 3120, 3121, 3130, Xerox WC 3119

ML2250, Xerox Phaser 3150, Xerox WC PE120

ML2550

ML6060, Xerox Docuprint P1210

ML3050, Xerox Phaser 3428

ML1610, 1640, 2010, 2240, Xerox WC PE220

TN2025, Xerox Docuprint 203/204

Xerox Docuprint 240/340



LASER PRODUCTS APRIL, 2011



MAG & DEVELOPER ROLLER

hp 3906(ax), 4092, 7115, 2613, 2624

hp 2612

hp 5949, 7553, 505

hp 435, 436, 285, 278

hp 4096, 2610, 6511, 7551, 255, 4127, 8061

hp 5942, 1338, 1339, 5945

hp 4129

hp 6000-6003

hp 7516

hp 540-543, 530-533

ML1210, Xerox Phaser 3110, 3210, Lexmark E210

ML1710, SCX4200, 4216, SF560, Xerox Phaser 3115, 3120, 3121, 3130, Xerox WC 3119

ML2250, Xerox Phaser 3150, Xerox WC PE120

ML2550

ML6060, Xerox Docuprint P1210

ML3050, Xerox Phaser 3428

ML1610, 1640, 2010, 2240, Xerox WC PE220

TN2025, Xerox Docuprint 203/204



LASER PRODUCTS APRIL, 2011



PCR

hp 3906(ax), 4092, 3903(vx), 2612, 7115, 2613, 2624, 5949, 7553, 505

hp 435, 436, 285, 278

hp 4096, 2610, 6511, 7551, 255, 4127, 8061, 364, 1338, 1339, 5945, 5942, 4191

hp 4129, 4182, 8543

hp 7516

hp 540-543, 530-533

ML1210, Xerox Phaser 3110, 3210, Lexmark E210

ML1710, SCX4200, 4216, SF560, Xerox Phaser 3115, 3120, 3121, 3130

ML2250, Xerox Phaser 3150, WC PE120

ML1610, 1640, 2010, 2240, 3050, Xerox Phaser 3428, Xerox WC PE220



LASER PRODUCTS APRIL, 2011



OPC DRUM

hp 3906(ax), 4092
hp 435, 436, 285, 278
hp 2612
hp 7115, 2613, 2624
hp 5949, 7553
hp 505
hp 255
hp 4096
hp 4127
hp 364
hp 1338, 1339, 5945, 5942
hp 2610
hp 6511, 7551
hp 4129
hp 7516
hp 6000-6003
hp 540-543, 530-533
hp 9700-9703(1500,2500), 3960-3963, 3971-3973 (2550)
hp 7560-7563, 6470-6473, 7581-7583
hp 9720-9723
hp 5950-5953
hp 9730-9733
ML1210, Xerox Phaser 3110, 3210, Lexmark E210
ML1710, SCX4200, 4216, SF560, Xerox Phaser 3115, 3120, 3121, 3130, Xerox WC 3119
ML2250, Xerox Phaser 3150, WC PE120
ML1610, 1640, 2010, 2240, 2510, 2570, SCX 4321, 4521, 4725, Xerox Phaser 3117, WC PE220
ML3050, 3470, Xerox Phaser 3428, 3435
ML3560, Xerox Phaser 3500
ML2850, 2450, SCX 4824, 4828
ML6060, Xerox Docuprint P1210
ML1660, 1661, 1665, 1666, SCX3200, 3205,
ML1910, 1915, 1916, 2525, 2580, SCX4600, 4605, 4610, 4623, CF650
Brother DR2000, TN350, 2025, 2050, HL2030, 2040, 2070, DCP 7020, MFC 7220, 7420, 7820, Xerox Docuprint 203, 204



LASER PRODUCTS APRIL, 2011



SMARTCHIPS

hp 2613, 5949, 2610, 6511, 1338, 5942, 7553, 7551, canon 308, 315

hp 2613X, 5949X, 2610X, 6511X, 1338X, 1339, 5945, 5942X, 7553X, 7551X, canon 308, 315

hp 435, 436, 255, canon 312, 313

hp 435, 436, 505, 364, canon 312, 313

hp 435, 436, 364, 285, 278, canon 312, 313

hp 7516, 7570, canon 309

hp 9700-9703, 3960-3963, 2670, 2681-2683, canon EP87, 301

hp 9704, 3964(DRUMKIT), 3971-3973, 2671-2673, canon EP87, 301(DRUMKIT)

hp 9720-9723, 9730-9733, canon EP85, 86

hp 6000-6003, 7560-7563, 6470-6473, canon 311

hp 530-533, 540-543, canon 316, 318

hp 310-313 (CP1025)

hp 320-323 (CP1525, CM1415)

xerox DP 240, 340

xerox DP 205, 255, 305

xerox Phaser 3428

xerox Phaser 3435

xerox Phaser 3200

xerox WC PE220

xerox WC 3119

xerox WC 3210, 3220

xerox DP C1110

xerox DP C1190

xerox DP C2100, C3210

xerox DP C2200, C3300

ML1630, SCX4500

ML1640, 2240 (**MLT-D108**)

ML1660, 1661, 1665, 1666 (**MLT-D104**)

ML1910, 1915, 2525, 2580, SCX4600, 4606, 4623, CF650 (**MLT-D105**)

ML2850

ML3470, 3471

SCX4300, 4310, 4315 (**MLT-D109**)

SCX4200

SCX4725

SCX4824, 4826, 4828 (**MLT-D209**)

SF560

CLP300, CLX3160

CLP310, 315, CLX3170, 3175 (**CLT-409**)

CLP320, 325, CLX3285 (**CLT-407**)



LASER PRODUCTS APRIL, 2011



TONER

hp mono universal (TCH-02)

hp mono universal (TCH-04)

hp 435, 436, 285, 278


samsung/ xerox mono universal

brother mono universal

hp color universal (TC-02)

samsung color

xerox color



EQUIPMENTS

vacuum cleaner

dust collector (double filtration with HEPA)

MISCELLANEOUS

cartridge plastic seal

reset gear for Brother TN350, 2025, 2050, Xerox Docuprint 203, 204

reset gear for Brother HL2140

reset gear for Brother HL3040

magnet sleeve cleaner

hp 1600, 2600, 2605 drum gear set

samsung fuse

laserjet refill & remanufactured products

drum powder

box for laserjet w/ insertion

conductive grease

